

# XW-III | Quick-Start Guide

1. Connect the module to power (Two AA batteries or 5VDC).
2. On a computer, scan for open Wi-Fi networks & connect to the SSID:  
`XW111-[Last six digits of Serial Number]`
3. If no Wi-Fi network is found called `XW111-[Last six digits of Serial Number]`, remove the front cover and press the 'Access Point' button for 2 seconds.
4. Once connected, open a web browser and enter:  
`http://192.168.1.2/setup.html`
5. Enter local Wi-Fi network settings and power cycle the module.  
*(You can also establish communications using WPS. See users manual.)*
6. The module will now attempt to connect to the specified Wi-Fi network.
7. Reconnect computer to Wi-Fi network and access the module through the Wi-Fi network to finish setup.

## Factory Default Settings

---

**SSID:** `XW111-[Last six digits of Serial Number]`

**Control Page Web Address:** `http://192.168.1.2`

**Control Password:** *(no password set)*

**Setup Page Web Address:** `http://192.168.1.2/setup.html`

**Setup Username:** `admin`

**Setup Password:** `webrelay` *(all lower case)*

See users manual for setup instructions:  
**[www.ControlByWeb.com/support/](http://www.ControlByWeb.com/support/)**

Rev 2.2

*XW-111 Bottom View*

5VDC Power Supply

